




meo

QUICK START GUIDE

REMOTE CONTROLLED FUCK MACHINE

ASSEMBLY OVERVIEW



01

Included parts

NO.	DESCRIPTION	QTY
1	Fuck Machine	1
2	Universal Plug-in Dildo Connector	1
3	Frame System	1
4	Feet	4
5	Remote Control	1
6	AC Power Adapter	1
7	Dildo	1
8	Wingnut Screw	1
9	North American Power Adapter	1
10	Toolkit (Allen/Hex Keys + Wrench)	3


02

Set up instructions

- 1 Connect the feet (4) to the frame (3).
- 2 Use the toolkit (10) to adjust the arm of the frame, and attach the Fuck Machine (1) using the wingnut screw (8).
- 3 Insert the dildo connector (2) into the Fuck Machine.
- 4 Plug in the Fuck Machine using the AC power adapter (6).
- 5 Control the Fuck Machine using the remote control (5).
- 6 Enjoy.

03

Using the remote



- 1 Use the central power button to turn the Fuck Machine on or off.
- 2 Use A+ and A- to adjust the amplitude.
- 3 Use S+ and S- to adjust the speed.